

astreëa®

THE PEDAL HAND SANITIZER

Quick Installation Guide

**It's so easy to
use and install
that it only needs
a single sheet
of paper**



This is a premium
quality product
manufactured
in Europe.



www.astreea.com



MADE IN THE EUROPEAN UNION BY ARSAT.
Copyright 2020 ARSAT Company. All rights reserved.
This product is patented, Patent N° 007864160-0001.
Any copy of product design and patented specifications
constitutes a patent infringement under European and
US patent law.

astrøea® *Open*

THE PEDAL HAND SANITIZER

- 1 Use the Allen-Key to unscrew the two screws and remove the original cap of the dispenser
- 2 Place the gasket on top of the pump
- 3 Place the new cap from the package on it
- 4 Use the Allen-Key to put the screws back on
- 5 Place **the button** on top of the new cap
- 6 You now have your new button attached



Please scan
QR CODE
for video
instructions

